

# TECHNICAL BULLETIN

POLYGLASS USA Inc.  
Corporate Office  
1111 West Newport Center Drive  
Deerfield Beach, Florida 33442  
Tel. (954) 233-1330 - Fax: (954) 418-4453  
Email: [technical@polyglass.com](mailto:technical@polyglass.com)  
Website: [www.polyglass.com](http://www.polyglass.com)

## Technical Bulletin #2019-M-02

TO: All **POLYGLASS** Polystick Users

CC: POLYGLASS Sales & Technical Services

Date: October 24, 2019

Author: James E. Akins,  
National Technical Services Manager

RE: Recover Applications over existing Polystick membranes – Wood deck

In our efforts to provide support to Polyglass Customers, we would offer the following guidelines for proper application, when applying a second layer of Polystick membranes, over a wood deck.

- Underlying wood deck shall be a minimum of 19/32" plywood or wood plank, Anchor sheet mechanically fastened to deck.
- Mechanically attached Anchor/Base Sheet shall be One (1) or more plies of an ASTM D 226 Type II or ASTM D 2626 sheet.
- Fastening pattern of Anchor/Base Sheet (as per FBC 1518.2 & 1518.4) shall be nails and tin caps applied in a 12" grid, 6" o.c. at a minimum 4" head lap (for base sheet only).
- Polystick Membranes are the following: Polystick IR-Xe, Polystick Dual Pro, Polystick Tile Pro, Polystick TU Max, Polystick TU P, Polystick TU Plus, or Polystick MTS Plus, self-adhered underlayments, per Polyglass application instructions.

In the event of application questions, all questions can be addressed to the POLYGLASS Technical Services Department.

10/25/2019; JEA