## **TECHNICAL BULLETIN**

POLYGLASS USA Inc. Corporate Office 1111 West Newport Center Drive Deerfield Beach, Florida 33442 Tel. (954) 233-1330 - Fax: (954) 418-4453

Email: technical@polyglass.com Website: www.polyglass.com

## Technical Bulletin #2020-M-02

Date: February 27, 2020

- Author: James E. Akins, National Technical Services Manager
- RE: SAFETY ADVISORY Steep-Slope Roof Loading with Battens for Polyglass Polystick® Underlayments packaged in plastic wraps

With respect to proper handling and installation of Polyglass Polystick products in the field, customer safety is our number one priority.

By publication of this Technical Bulletin, Polyglass USA Polystick underlayment membrane products packaged in plastic wraps require the application of batten strips to approved substrates including but not limited to plywood, OSB, and anchor sheets prior to loading these products on steep slope roofing projects. This practice will assure safe and secure loading of these products prior to installation.

Care should be taken during the underlayment loading procedure as rolls may slide if batten strips are not installed. Required batten strips may be removed during installation of the underlayment membranes.

Polyglass assumes no liability for damages for underlayment rolls loaded on steep roofs where batten strips are not installed.

In the event of more detail application and warranty questions, all questions can be directed to the POLYGLASS Technical Services Department at 866-794-9659.

V3.3/4/2020; JEA

WATERPROOFING MATERIALS AND INSULATING SYSTEMS

