



**GENERAL NOTATIONS:**

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. Wood blocking may be required at drain, depending on insulation thickness and type (not shown for clarity).
3. For heat fused membrane applications, set metal flashing onto heated softened membrane.
4. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
5. Drain Installation and re-equipment by others.

**POLYGLASS**



[polyglass.us](http://polyglass.us)

1111 West Newport Center Drive  
Deerfield Beach, FL 33442

Technical Service: (866) 794-9659  
[technical@polyglass.com](mailto:technical@polyglass.com)

**Description:**

## ROOF DRAIN DETAIL (Typical)

**Number:**

PG-LS-DRN-01A

**Revision Date:**

070823