



GENERAL NOTATIONS:

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. For heat fused membrane applications, set metal flashing onto heated softened membrane.
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flashed metal to be 3" minimum and fully bonded to primed metal surface.



polyglass.us

1111 West Newport Center Drive
 Deerfield Beach, FL 33442
 Technical Service: (866) 794-9659
technical@polyglass.com

Description:

**VENT PIPE FLASHING WITH LEAD
 SLEEVE DETAIL (Typical)**

Number:

PG-LS-PEN-02A

Revision Date:

070623