



GENERAL NOTATIONS:

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. For heat fused membrane applications, set metal flashing onto heated softened membrane.
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flanged metal to be 3" minimum and fully bonded to primed metal surface.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
Deerfield Beach, FL 33442

Technical Service: (866) 794-9659
technical@polyglass.com

Description:

**VENT PIPE FLASHING WITH LEAD
SLEEVE DETAIL (Typical)**

Number:

PG-LS-PEN-02A

Revision Date:

070823