



**GENERAL NOTATIONS:**

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. For heat fused membrane applications, set metal flashing onto heated softened membrane.
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flanged metal to be 3" minimum and fully bonded to primed metal surface.
5. Pitch pans filled with Approved Pourable Sealer



[polyglass.us](http://polyglass.us)

1111 West Newport Center Drive  
Deerfield Beach, FL 33442  
Technical Service: (866) 794-9659  
[technical@polyglass.com](mailto:technical@polyglass.com)

**Description:**

**VENT PIPE WITH PENETRATION  
POCKET DETAIL (Typical)**

**Number:**

PG-LS-PEN-03A

**Revision Date:**

070823