



**GENERAL NOTATIONS:**

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. Wood blocking may be required at drain, depending on insulation thickness and type (not shown for clarity).
3. Cleaning and Preparation - Clean and prepare the surface by brooming mild detergent & water rinse or as required to remove any conditions that could adversely affect the adhesion of primers and liquid materials.
4. Surfaces to receive Polyglass Liquid Flashing System may need to be primed, depending on the surface.
5. Polyglass Liquid Flashing System consists of: Polyglass PMMA Flashing Base Coat, embed Polyglass PMMA Polyester Reinforcement covered with Polyglass PMMA Flashing Top Coat.
6. Illustration and notations intended for generalized application only. Please refer to Product Data Sheets for additional information.



**polyglass.us**

1111 West Newport Center Drive  
 Deerfield Beach, FL 33442  
 Technical Service: (866) 794-9659  
 technical@polyglass.com

**Description:**

**POLYGLASS PMMA DRAIN  
 DETAIL (Typical)**

SCALE: NTS

**Number:**

PG-PMMA-DRN-01

**Revision Date:**

051622