



GENERAL NOTATIONS:

1. For heat fused membrane applications, set metal flashing onto heated softened membrane.
2. Extension of field base/piles 1" min above top of cant, required (not shown for clarity).
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flanged metal to be 3" minimum and fully bonded to prime metal surface.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
Deerfield Beach, FL 33442
Technical Service: (866) 794-9659
technical@polyglass.com

Description:

**INSIDE CORNER MEMBRANE FLASHING
TYPICAL DETAIL**

NOT DRAWN TO SCALE

Number:

PG-LS-WALL-04

Effective Date:

073124