



GENERAL NOTATIONS:

1. Modifleece is a fleece-backed SBS modified bitumen roofing membrane base sheet for use in multi-ply low-slope roofing systems for new or re-roof applications. The fleece-backing must be completely dry and free from any type of moisture prior to installation. A self-adhered or torched Polyglass cap sheet is required to complete the roofing system.
2. Typical Applications: Use as base ply adhered directly to Lightweight Insulating Concrete or Existing APP/SBS modified bitumen roofing system and other approved substrates.
3. Modifleece is applied using Polyglass LRF CR low rise foam adhesive in a spatter pattern.
4. The self-adhered side laps are protected with a release film which is removed at the time of application. Broom the side laps with a push broom.
5. The surfaces must be relatively even, clean, completely dry, smooth, and free of sharp edges, fins, loose or foreign materials, oil, grease, and other materials that may damage the membrane. Rough surfaces that could damage the membrane must be overlaid with acceptable insulation/recover board.
6. For more detailed installation instructions refer to the Product Data Sheet.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
Deerfield Beach, FL 33442
Technical Service: (866) 794-9659
technical@polyglass.com

Description:

MODIFLEECE - END LAP DETAIL

NOT DRAWN TO SCALE

Number:

PG-LS-MDFC-01

Effective Date:

080824