



**GENERAL NOTATIONS:**

1. For heat fused membrane applications, set metal flashing onto heated softened membrane.
2. Extension of field base/piles 1" min above top of cant, required (not shown for clarity).
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flanged metal to be 3" minimum and fully bonded to prime metal surface.

**POLYGLASS**



**polyglass.us**

1111 West Newport Center Drive  
Deerfield Beach, FL 33442  
Technical Service: (866) 794-9659  
technical@polyglass.com

**Description:**

**OUTSIDE CORNER MEMBRANE FLASHING TYPICAL DETAIL**

NOT DRAWN TO SCALE

**Number:**

PG-LS-WALL-03C

**Effective Date:**

073124