



GENERAL NOTATIONS:

1. Metal Edge Flashing, Wood Blockings and Attachments shall comply with ANSI/SPRI ES-1
2. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
3. Detail only applicable when installing a membrane field wrap application, otherwise use approved metal flashings.
4. Cleaning and Preparation - Clean and prepare the surface by brooming mild detergent & water rinse or as required to remove any conditions that could adversely affect the adhesion of primers and liquid materials.
5. Surfaces to receive Polyglass Liquid Flashing System may need to be primed, depending on the surface.
6. Illustration and notations intended for generalized application only. Please refer to Product Data Sheets for additional information.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
 Deerfield Beach, FL 33442
 Technical Service: (866) 794-9659
 technical@polyglass.com

Description:

POLYGLASS PMMA PARAPET LOW FLASHING DETAIL (TYPICAL)

NOT DRAWN TO SCALE

Number:

PG-PMMA-WALL-01

Effective Date:

080824