



**GENERAL NOTATIONS:**

1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
2. For heat fused membrane applications, set metal flashing onto heated softened membrane.
3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
4. Membrane laps at flanged metal to be 3" minimum and fully bonded to primed metal surface.

**POLYGLASS**



**polyglass.us**

1111 West Newport Center Drive  
 Deerfield Beach, FL 33442  
 Technical Service: (866) 794-9659  
 technical@polyglass.com

**Description:**

**VENT PIPE FLASHING WITH LEAD SLEEVE DETAIL (TYPICAL)**

*NOT DRAWN TO SCALE*

**Number:**

PG-LS-PEN-02B

**Effective Date:**

081524