

GENERAL NOTATIONS:

- 1. Wood blocking may be slotted for venting of wet-fill decks or other applicable constructions.
- 2. For heat fused membrane applications, set metal flashing onto heated softened membrane.
- 3. Membrane end laps to be a minimum 6" and fully adhered at all membrane to membrane seams.
- 4. Membrane laps at flanged metal to be 3" minimum and fully bonded to primed metal surface.
- 5. Pitch pans filled with Approved Pourable Sealer

POLYGLASS

polyglass.us

1111 West Newport Center Drive Deerfield Beach, FL 33442 Technical Service: (866) 794-9659

technical@polyglass.com

Description: VENT PIPE FLASHING WITH PENETRATION POCKET DETAIL

(TYPICAL)

NOT DRAWN TO SCALE

Number: PG-LS-PEN-03D E

Effective Date:

081524