



GENERAL NOTATIONS:

1. Modifleece is a fleece-backed SBS modified bitumen roofing membrane base sheet for use in multi-ply low-slope roofing systems for new or re-roof applications. The fleece-backing must be completely dry and free from any type of moisture prior to installation. A self-adhered or torched Polyglass cap sheet is required to complete the roofing system.
2. Typical Applications: Use as base membrane adhered directly to Lightweight Insulating Concrete (LWIC) or Existing APP/SBS modified bitumen roofing system and other Polyglass approved substrates.
3. Modifleece is applied using Polyglass low rise foam adhesive in a uniform spatter pattern.
4. The self-adhered side laps are protected with a release film which is removed at the time of application. Roll or broom the side laps to ensure complete contact.
5. Substrate surfaces to be even, clean, dry, smooth, and free of sharp edges, loose or foreign materials such as; oil, grease, and other contaminants that may damage the membrane. Rough surfaces that could damage the membrane must be overlaid with acceptable insulation/recover board.
6. Elastoflex SA V Flashing Strips must be a minimum 9" wide.
7. For more detailed installation instructions refer to the Product Data Sheet.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
Deerfield Beach, FL 33442
Technical Service: (866) 794-9659
technical@polyglass.com

Description:

MODIFLEECE - END LAP DETAIL

NOT DRAWN TO SCALE

Number:

PG-LS-MFC-01

Effective Date:

071425