



GENERAL NOTATIONS:

1. Water Damning Membrane must fully adhere to prevent any water migration into the new roof system.
2. Refer to Product Data Sheets for specific information regarding proper installation and handling of all Polyglass products being used.

POLYGLASS



polyglass.us

1111 West Newport Center Drive
Deerfield Beach, FL 33442
Technical Service: (866) 794-9659
technical@polyglass.com

Description:

**LOW-SLOPE TIE-IN
TO EXISTING ROOF**

NOT DRAWN TO SCALE

Number:

PG-LS-TIE-02

Effective Date:

121724