

Technical Bulletin #2019-M-02.1

To: All POLYGLASS Users
CC: POLYGLASS Sales & Technical Services
Re: **Guidelines for Installing Polystick Underlayment Over an Existing Self-Adhered Underlayment on a Wood Deck outside of Florida**

In our continued effort to support our customers, Polyglass offers the following guidelines when applying a new layer of Polystick membranes over a wood deck that already has an existing self-adhered membrane installed.

The applications below do not require the removal of the existing self-adhered underlayment. The anchor sheet, as outlined below, will be applied over the existing underlayment and attached to the wood deck using approved fasteners.

- Existing wood deck shall be a minimum of 15/32" plywood or wood plank.
- Mechanically attach the approved anchor sheet through the existing underlayment into the wood deck. Polyglass PolyAnchor HV is the recommended product for this application.
- The use of ASTM D226, Type II felts is allowed for all roof coverings as long as the system meets the local codes of the authority having jurisdiction.
- The fastening pattern must comply with the local codes of the authority having jurisdiction. Depending on local jurisdiction, the system may be required to meet a Maximum Design Pressure (MDP) as specified for the project.
- An approved Polystick underlayment must be installed prior to the application of the final roof covering, in accordance with Polyglass' guidelines.

For more detailed application or warranty inquiries, please contact the Polyglass Technical Services Department at 866-794-9659 or via email at Technical@Polyglass.com.



Rev 011725